


Muslin Preparation for a base Sleeve Sloper

- 1** Prepare a Muslin
18" X 25"
Draw straight line
in the middle




- 2** Fold your muslin in
half from your drawn
straight line




- 3** From bottom go up to 1" and
draw across

From 1" go up to 17" and
draw across



- 4** Devide 17" into two
and draw a straight
line across




- 5** After folding and drawing your Wrist, Elbow and Bicep Lines you can measure your own arm, or your arm piece measurements and start marking.

You don't have to make a Sleeve Sloper for your own size just yet.

If your dress form that you draped your bodice sloper and your muslin arm piece is in dress size 6,8 or 10 follow the measurement below. If not then measure yourself and find your own numbers.

This is an easy chart to follow and make your own base sleeve sloper for any measurement you want.




Measure your arm Bicep
or divide 15" Circumference
in half and mark at $7 \frac{1}{2}$ "

Measure your arm elbow,
or divide 13" Circumference
in half and mark at $6 \frac{1}{2}$ "


Measure your arm Wrist,
or divide 9" in half and
mark at $4 \frac{1}{2}$ "

6



Mark 6 1/2" from bicep line up and draw across

7



6 1/2"

3 1/4"


Bicep Line

Elbow Line

Wrist Line

Mark halfway between bicep and your top of sleeve crown line and draw across

8



Fold the hem of your sleeve in and cut for easier cut.

From your bicep point mark 2" in on your line, and draw straight up

Add 1/2" Seam Allowance to your outer lines and cut

Sew your seam from bicep line down, and leave to curved line to top open

9



Sew and close arm seam from under arm to wrist

Fold the hem of the seam and sew the arm